
RECHARGEABLE LED MULTI TOOL

PART NO. 17945



Detachable 13 in 1 rechargeable LED multi tool is easy-to-use featuring safe opening & closing mechanism and a nylon pouch for durable storage while carrying. The stainless steel functional head and bits holder are matte finish. The aluminum handle has a black oxidation and brush finish, while the knife, saw and rope cutter are all satin finish.



CHARGING

Use common 2.0 USB cable to charge the battery. When the battery is fully charged, good for 1.5 hours of continuous use.



BITS USE

There are 4 pieces of bits inside the handle. Open the bits case marked "Bits inside" then, put the bit you need into the bit holder in the end of the handle. After use, place the bit inside the bits case and close the case by pressing the case door.



DETACHING

Use your thumb to slide down the button, lift the detachable part with your thumb & index finger. It is detached when you hear the "click" sound.



CONNECTING

There are 2 small hooks on the bottom of handle, place the 2 grooves (next to the LED light) on them and lie along with the handle. Push to the right while sliding down the button by thumb. When you hear a "click" sound, it's connected.



PRODUCT SPECIFICATIONS

ITEM DESCRIPTION 17945

RECHARGEABLE LED MULTI TOOL

UPC CODE 045256179452









